


EFFECTIVE DATE
July 15, 1970

NuTone PARTS LIST

MODEL
2028
ELECTRONICS



REF.	PART NO.	*Part used on other model/s	PART DESCRIPTION
1	31405		Contact Set (2)
2	34020		Potentiometer w/washer & nut
3	32550		Contact Wire
4	36032		Speaker 4"
5	32054		Panel
6	31909		Knob
7	31619		Push-Talk Button
*	32035		"A" Frame
*	40084		Envelope Assy. (mtg. screws)
			* Not Shown

Order Parts From: PARTS DEPT. C/O

NuTone **SCOVILL**

DIVISION

1000 East Main Street, Springfield, O. 45527