

## PARTS LIST

Ref. No.	Part No.	Description
----------	----------	-------------

### TRANSISTORS

TR4	C36578	2N4255 Converter
TR5	C36578	2N4255 1st IF
TR6	C36578	2N4255 2nd IF
TR7	C36580	36560 AF Amp.
TR8	C36577	36577 Driver
TR9	C36580	36580 Intercom Preamp
TR10	C36579	Audio Output

### DIODES

D4	A36508	AM Detector
D5	A36508	AM Overload
D6	A36539	Zener Power Regulator
D8	B36564	Silicon Rectifier
D9	B36564	Silicon Rectifier
D10	B36564	Silicon Rectifier
D11	B36564	Silicon Rectifier

### CAPACITORS

C23	C35079	Tuning Gang 2 Section
C28	C35101-135	7.5pf @ 1000V Ceramic Disc
C29	C35100-141	0.05mfd @ 50V Ceramic Disc
C30	D35068-108	10mfd @ 6V Electrolytic
C39	C35100-142	330pf @ 25V Ceramic Disc
C48	C35100-152	0.01mfd @ 50V Ceramic Disc
C49	D35068-103	100mfd @ 15V Electrolytic
C50A	C35080	30mfd @ 35V Electrolytic
C50B		300mfd @ 20V Electrolytic
C50C		500mfd @ 50V Electrolytic
C50D		500mfd @ 50V Electrolytic
C51	C35100-141	0.05mfd @ 50V Ceramic Disc
C52	C35100-153	0.03mfd @ 50V Ceramic Disc
C53	D35068-111	390mfd @ 3V Electrolytic
C54	B35024	0.47mfd @ 75V Polyester Film
C55	C35100-134	470pf @ 1000V Ceramic Disc
C56	C35100-140	0.02mfd @ 50V Ceramic Disc
C57	C35100-127	0.1mfd @ 100V Ceramic Disc
C58	C35100-139	0.01mfd @ 25V Ceramic Disc
C59	C35100-139	0.01mfd @ 25V Ceramic Disc
C60	C35100-139	0.01mfd @ 25V Ceramic Disc

### CONTROLS AND RESISTORS

R41	A33028-391	390Ω, 10%, 2 Watt, Wirewound
R42	A33101-151	150Ω, 10%, 1/2 Watt, Carbon
R43	A33101-394	390K, 10%, 1/2 Watt, Carbon
R45A	B34038	500K, Tone Control, (Includes M30 Off-On Switch
R45B		100K, Systems Volume Control
R46	A33040-683	68K, 5%, 1/2 Watt, Film
R55	A33028-471	470Ω, 10%, 2 Watt, Wirewound
R56	A33028-082	8.2Ω, 10%, 2 Watt, Wirewound
R58	A33028-150	15Ω, 10%, 2 Watt, Wirewound
R59	A34023	2 Meg Level Set Control
R67	A33101-332	3.3, 5%, 1/2 Watt, Carbon
R68	A33028-062	0.2Ω, 10%, 2 Watt, Wirewound
R69	A33101-151	150Ω, 10%, 1/2 Watt, Carbon
R71	A33101-033	3.3Ω, 5%, 1/2 Watt, Carbon

Ref. No.	Part No.	Description
----------	----------	-------------

### CONTROLS AND RESISTORS (Cont'd.)

R73	A33101-153	15K, 10%, 1/2 Watt, Carbon
R74	A33101-273	27K, 10%, 1/2 Watt, Carbon
R75	B34029	20 Master Speaker Volume Control

### COMPONENT COMBINATIONS

P1	B37541	Convertor Couplate - (3) .01mfd, 22K, 330Ω, 10K, 1500Ω.
P2	B37538	1st IF Couplate - (3) .01mfd, .005mfd, 470Ω, 90K, 10K, 1200Ω.
P3	B37539	2nd IF Couplate - .01mfd, (2) .02mfd, .005mfd, 560Ω, 2200Ω, 15K, 330Ω.
P5	B37540	Audio Detector Couplate - .01mfd, (2) .02mfd, 2700Ω, 2200Ω, 10K.
P6	B33031	Audio Couplate - 180K, (2) 68K, 56K, 2200Ω, 10K, 390Ω, 1200Ω.
P7	B33032	Intercom Couplate - 4700Ω, 560K, 820K, 6800Ω, 100K, 15K, 680Ω.

### TRANSFORMERS

T5	C30541	3rd AM IF
T6	C30540	2nd AM IF
T7	C30542	1st AM IF
T8	C30547	Intercom Input
T9	C30575	Output

### COILS

L6	B30573	AM Antenna
L7	C30067	AM Oscillator

### REMOTE SPEAKERS

	Model 2028	
	Model N2021	
	Model 2014	
	Model N2006	

### MISCELLANEOUS

M1	B34579	Radio-Phono, 2 Position Slide Switch
M2	C34547	Talk-Listen, 3 Position Lever Switch
M3		Off-On Switch on R45
M4	40765	Door Switch Assembly
M5	B34578	Door, 2 Position Slide Switch
	B36025	Speaker, 5" 3.2Ω
J1	40776	Phono Connector Ass'y.
	40759	Main Printed Circuit Board Ass'y.
		Complete with Components
	A31934	Dial Lamp (G. E. 1819)
	B40740	Front Panel Ass'y.
	R32387	Front Panel
	B32363	Dial Lens
	B31891	Knob, Tuning
	B31892	Knob, Speaker
	B31890	Knob, Volume
	A31604	Knob, Tone
	C31861	Knob, Lever
	B31886	Lampholder
	A31882	Dial Pointer
	40614	Power Transformer

**NuTone**

Madison and Red Bank Rds., Cincinnati, Ohio 45227

Printed in U.S.A.  
Part No. 45457

