


NuTone

Supplemental Information

REVISED PARTS LIST



RECORD CHANGER MODEL 2073

NuTone

Madison and Red Bank Roads, Cincinnati 27, Ohio

Rev. 6/68 1a

This Supplement cancels the previous Parts List - Page 16 - of the NuTone Service Manual for Record Changer, Model 2073.

The New Parts List contained in this Supplement is to be used for Parts identification when servicing the Model 2073 Changer; and to be used for the ordering of replacement parts.

The earlier Model 2073 Changers were supplied by V. M. under Manufacturer's Model No. 1257-425.

The later Model 2073 Changers were supplied by V. M. under Manufacturer's Model No. 1287-726.

The Manufacturer's Model No. can be found on the underside of the Baseplate of the individual changer.

The Exploded View of the Changer as shown in Figures 11 and 12 on Pages 8 and 9 of the 2073 Service Manual is to be used when servicing either one of the V. M. Models of the 2073.

There are slight differences in some of the parts used on the two different Models. Although these parts have the same Ref. No. on the Exploded View, and serve the same function in both units, they will be listed in the Parts List under different NuTone Part Numbers and different V. M. Part Numbers. These different Part Numbers are noted in the new Parts List.

A few of the Parts are used on only one of the Models, and this is also shown on the new Parts List.

Parts marked "*" used only in Model 1257-425.

Parts marked "***" used only in Model 1287-726.

Ref. No.	NuTone Part No.	V-M Part No.	Description	Ref. No.	NuTone Part No.	V-M Part No.	Description
1	40441	28904-D	Turntable Assembly	53	**31643	27144	Cap, Trip Lever
2	31521	18046-A	Turntable Mat	54	*31341	5339	Pawl Lever
3	31522	31391-11	Mounting Bolt	54	**31644	33722	Clutch, Trip Lever
4	31523	3974	Fiber Washer (Idler Spacing)	55	*31309	5338	Trip Pawl Spring
5	31524	24411	"E" Ring (Idler Retaining)	56	*40171	22744	Gear Assembly
6	31525	22915	Idler Wheel	56	**40531	33811	Gear Assembly
7	31331	5022	"C" Washer, Motor Mounting	57	*40172	2569	Trip Lever Assembly
8	31527	3489	Grommet, Motor Mounting	57	**40532	27149	Trip Lever Assembly
9	*31279	9823	Screw, Works Assembly Mounting	58	31590	30778-2	Screw, Slide Mounting
9	**31622	35578-7	Screw, Works Assembly Mounting	59	*40457	25409	Ejector Bracket Assembly
10	40442	30135-527	Record Support Arm Assembly	59	**40533	35588	Ejector Bracket Assembly
11	31299	29224	Set Screw, Record Support	60	*31586	9823	Screw, Ejector Mounting
12	31542	18339	Phono Socket (Dual)	61	31304	2925	Spring, Reset Lever
13	31541	26802	Screw, Phono Socket Mounting	62	31340	20886	Reset Lever
14	31528	25267-527	Tone Arm	63	*31302	2579	Spring, 7" Lever
15	31266	4922	Pivot Button	63	**31639	35612	Spring, 7" Lever
16	31263	4923	Pivot Screw	64	*31339	2581	7" Lever
17	31531	25720	Lift Screw	64	**31640	33652	7" Lever
18	31533	29081	Hinge Screw	65	31303	9849	Screw, 7" Lever Mounting
19	31530	24638	Adjustment Spring	66	*31596	6883	Washer
20	31529	21861	Tone Arm Clip	67	31592	2585	Spring, Escape Lever
21	40446	25364	Spindle	68	*31589	24020	Spring, Slide Detent
21A			Spindle Spring (Part of Item 21)	68	**31637	27147	Spring, Slide Detent
22	31540	23839-B	Stylus Pad	69	31562	24452	12" Record Selector - Lever
23	31544	25215	Wire Hold-Down Spring	70	31290	14951	12" Record Selector Spring
24	31545	25725-1	Screw Retaining (Wire Hold-Down Spring)	71	31563	26792	"C" Washer, 12" Record Selector Retaining
25	*31546	25367	Record Support Guide Assembly	72	31564	26795	"C" Washer, Control Shaft
25	**31626	35547	Record Support Guide Assembly	73	*31291	2580	Rubber Bumper
25A			Spring (Part of Item 25)	73	**31623	30317	Rubber Bumper, 7" Lever
26	31547	4857	Screw, Retaining (Record Support Guide Assy)	74	*40451	25362	Frame Assembly
27	31286	33715	Reject Rod	74	**40525	35437	Frame Assembly
28	31287	2916	Screw, Retaining (Rest Post)	75	31565	16807	Shift Lever
29	31591	31350	Spring (Reject Rod)	76	31566	16808	Shift Lever Pin
30	31550	27164	Retraction Rod	77	31307	6713	Screw, Shift Lever Mounting
30A	**32601	26805	Sleeving (Retract Rod)	78	*34521	21338	AC Switch
31	31629	35546	Spring, Idler Tension	78	**34552	33945	AC Switch
32	31549	22694	Mounting Bolt Clip	79	*40452	26812	Control Shaft Assembly
33	*31543	29057	Control Rod - Speed	79	**40526	35150	Control Shaft Assembly
33	**31625	33992	Control Rod - Speed	80	31568	24073	Screw, Works Mounting
34	40524	35447	Motor, AC - 117V, 60 cycle (Assembly)	81	*31569	24805	Return Spring
35	31574	25819	Spring, Manual Actuator	81	**31632	35597	Return Spring
36	31564	26795	"C" Washer, Control Lever	82	40527	33943	Locator and Bushing Assembly
37	31558	15212	"E" Ring, Idler Arm Assembly Mounting	83	31295	5828	Locator Ring
38	31557	27177	Stud, Idler Arm Assembly	84	*31570	20576	Cover, AC Switch
39	31630	35513	Yoke, Idler Arm Assembly	85	*31296	4212	Spring, AC Switch Cover Retaining
40	31560	25432	Compression Spring	86	*40170	19153	Retard Assembly
41	40523	35538	Idler Arm Assembly	86	**40528	35439	Retard Assembly
41A			Idler Height Adjustment Screw (Part of Item 41)	87	*31307	6713	Screw, Retard Lever Assembly, Retaining
42	31602	14675	Nut (Bottom), Ground Wire Retaining	87	**31633	9849	Screw, Retard Lever Assembly, Retaining
43	31602	14675	Nut (Top), Ground Wire Retaining	88	40456	25365	Finger & Shaft Assembly
44	*31346	19800	Four Circuit Connector (Plastic)	89	31338	9557	Retard Lever
45	31593	26796	"C" Washer, Gear Retaining	90	31297	9510	Spring, Anti-Skate
46	31265	6884	Spindle Ball Bearing	91	31585	9509	Spring, Lift Pin
47	31292	9762	Spring Washer	92	31563	26792	"C" Washer, Trip Link Mechanism
48	31299	29224	Set Screw Spindle	93	31563	26792	"C" Washer
49	31331	5022	"C" Washer	94	*31588	25707	Trip Link
50	*31594	20762	Safety Spring	94	**31636	27261	Trip Link
51	*31595	25379	Push Rod, Spindle Actuator	95	*40173	24801	Slide Assembly
51	**31638	33948	Push Rod, Spindle Actuator	95	**40529	35438	Slide Assembly
52	31563	26792	"C" Washer, (12" Lever Ret.)	96	31306	16817	Spring, Retard Arm
53	*31308	22739	Spring, Trip Lever	97	31592	2585	Spring, SHUT OFF Lever

Ref. No.	NuTone Part. No.	V-M Part No.	Description
98	*40196	6966	Shut-Off Lever Assembly
98	**40530	35149	Shut-Off Lever Assembly
99	31627	29378	Record Support Shaft
100	31264	6876	Turntable Bearing
101	31262	6877	Washer, Turntable Bearing
102	31538	25526A-46	Speed Knob
103	31537	25527A-46	On-Off-Rej. Knob
104	*40447	22723	Control Lever Assembly, REJ.
104	**40521	33812	Control Lever Assembly, REJ.
105	*40448	25419	Control Lever Assembly, SPEED
105	*40522	33989	Control Lever Assembly, SPEED
106	31573	31124-A22	Rest Post, Tone Arm
107	31555	30190	Speed Selector Cam
108	31554	29376	Spring, Speed Selector Cam
109	31307	6713	Screw, Retaining (Speed Selector Cam)
110	*31580	25261	Fiber Washer
111	31399	29288-F	Cartridge
112	31576	21813-A	"O" Ring, Turntable Retaining
113	31583	24445	Lift Pin
114	31273	11498	Keys Nut
115	31584	24240	Safety Spring
116	31396	4339	Safety Plate
117	*31587	26808	Thrust Washer
118	40443	29082	Hinge Arm Assembly
118A	31624	31114	Set Down Adjustment Screw (Part of Item 118)
119	31601	22885	Hinge Arm Bearing Retainer
120			Motor Mounting Bracket (Part of Item 34)
121			Screw, Motor Mounting (Part of Item 34)
122			Nut, Motor Mounting (Part of Item 34)
123			Lock Washer, Motor Mounting (Part of Item 34)
124			Spacer, Motor Mounting (Part of Item 34)
125			Stud, Motor Mounting (Part of Item 34)
126	*31552	23548	Insulated Plate (Four Circuit Connector)
127	*31551	8686	Screw, Four Circuit Connector - Retaining
128	32265	30908-531	Baseplate
131	*31571	22849	Screw, Retard Mounting
131	**31307	6713	Screw, Retard Mounting
132	*31307	6713	Screw, Retard Mounting
			NOTE:
			Refer to Page 9, Fig. 12 - Screw adjacent to Ref. No. 56 remains Ref. No. 131. (Both Models).
			Refer to Page 9, Fig. 12 - Screw adjacent to Ref. No. 96, Spring Retard Arm, changes from Ref. No. 131 to Ref. No. 132 in earlier Model No. 1257-425.
	31634	35424	Dampening Pad (3 required) (Not shown on Exploded Drawing)
	31635	35499	Clip, Motor Lead (Not Shown)
	40534	30337-4	Ground Wire & Lug Assembly (Not shown on Drawing)

THE FOLLOWING CHANGES SHOULD BE ENTERED IN SERVICE MANUAL

ADD: "Ref. 128 Base Plate to Fig. 11, Page 8."
CHANGE: "Ref. 129 to Ref. 109, Fig. 2, Page 3."
ADD: Parts List Column 2
60 **31641 3578-7 Screw Eject Mounting