


PARTS LIST

MODEL	2086-2087 Horn Speaker ELECTRONICS
EFFECTIVE DATE	April 1, 1972



REF.	PART NO.	* Part used on other models.	NOMENCLATURE
1	40619		Horn Speaker Assy. Ref. No's 2 thru 16
2	32148	*	"U" Bracket
3	32364	*	Horn
4	32365	*	Rear Housing
5	36023		Cone Speaker - 4 Ohm
6	35033	*	Condensor - 30 mfd
7	32570	*	Cable
8	31798	*	Cable Clamp
9	32366	*	Sound Absorber
10	32149	*	Unit Strap
11	36026		Unit Assy, (Speaker 4 ohms)
12	32367	*	Front Housing
13	32368	*	Reflector
14	31795	*	Stud (2 required)
15	31794	*	Lock Washer

PLEASE SEE OTHER SIDE

NuTone Division

Scovill

Order Parts From: Parts Department c/o
NuTone
Madison & Red Bank Road
Cincinnati, Ohio 45227

REF.	PART NO.	* Part used on other models.	NOMENCLATURE
16	31796	*	Wing Nut
17	40551		Bezel & Control Assy. Ref. No's 18,19,20,21,22,23,24 & 25
18	34026		Potentiometer, Dual
19	31405		Contact (2 required)
20	32550		Contact Wire
21	32467		Insert
22	31907		Pushbutton
23	31911		Knob - Small
24	31910		Knob - Large
25	32463		Bezel only