

REPLACEMENT PARTS LIST

Ref. No.	NuTone Part No.	Description
RESISTORS (cont'd)		
R620	33101-822	8.2K
R621	33101-473	47K
R622	33101-683	68K
R623	33101-473	47K
R624	33101-473	47K
R625	33101-103	10K
R626	33101-682	6.8K
R627	33101-331	330
R628, R629	33101-103	10K
R630, R631	33101-392	3.9K
R632	33101-101	100
R633	33101-332	3.3K
CAPACITORS		
C601	35068-104	33 + 100% - 10% 35 WVDC Electrolytic
C602	35100-141	.05 + 80% - 20% 50 WVDC Ceramic
C603, C604	35100-120	.001. 500 WVDC Ceramic
C605	35100-139	.01 + 80% - 20% 50 WVDC Ceramic
C606	35068-106	2.2 + 100% - 10% 50 WVDC Electrolytic

Ref. No.	NuTone Part No.	Description
RELAYS		
RY1	39038-000	Talk/Listen, 4 PDT, American Zettler #1309-4C-12D Guardian Electric #1315-4C-12D
RY2, RY3	39203-000	Door and Standby, 2 PST Electronic Application Co. #121AXB96 OAAA Elec-trol #R5191-2
RY4	41136-000	Stepping Relay Assy.
	39120-000	Stepping Relay
	38253-000	Bracket
	16851-004	Screw #6 - 32 Bd. Hd. Mach. 1/4 Lg., 2 Req'd.
	31851-000	Cable Clamp
	39123-008	Indicator Disc.
	31253-038	Lockwasher #6
	11077-003	Hex Nut #6
MISCELLANEOUS P. C. PARTS		
	39259-000	Relay Socket — P. C. Mount
	38105-003	Mtg. Bracket — Transistor
	8603-003	Screw #4X 1/4 Lg. Sit. Pan "B"
	31826-000	Cable Clamp
	25641-020	Washer

PARTS LIST

Ref. No.	NuTone Part No.	DESCRIPTION
TRANSISTORS		
TR-601 & 602	36509 (Darlington)	
TR-603	*36577 36509 (Darlington)	
TR-604	36577	
TR-605	36603	
TR-606	*36580 36590 (Darlington)	
TR-607	36580	
TR-608	36580	
TR-609	36580	
* Used in Early Production		
DIODES		
D-601	36504 (Motorola 1N5239)	9.1 Volt Zener
D-602	36549 (Motorola MR2065 or 1N4002)	
D-603	36601 (Motorola 1N5228)	3.9 Volt Zener
D-604	*36602 (Motorola 1N5248) 36609 (Motorola 1N5246)	18 Volt Zener 16 Volt Zener
D-605	36549 (Motorola MR2065 or 1N4002)	
D-606	36549 (Motorola MR2065 or 1N4002)	
D-607	36549 (Motorola MR2065 or 1N4002)	
D-608	36601 (Motorola 1N5228)	3.9 Volt Zener
D-609	36504 (Motorola 1N5239)	9.1 Volt Zener
* Used in Early Production		
CAPACITORS		
C-601	35068-104	30mfd. @ 30 Volts
C-602	35100-141	.05mfd. @ 50 Volts
C-603	35100-120	.001mfd. @ 50 Volts
C-604	35100-120	.001mfd. @ 50 Volts
C-605	35100-139	.01mfd. @ 50 Volts
RESISTORS		
R-601	33101-223	22K ohms
R-602	33101-683	68K ohms
R-603	33101-683	68K ohms
R-604	33101-473	47K ohms
R-605	33101-473	47K ohms
R-606	33101-683	68K ohms
R-607	33101-683	68K ohms
R-608	33101-473	47K ohms
R-609	33101-473	47K ohms
R-610	33101-104	100K ohms
R-611	33101-222	2.2K ohms
R-612	33101-333	33K ohms
R-613	33101-333	33K ohms
R-614	33101-222	2.2K ohms
R-615	33101-682	6.8K ohms
R-616	33101-682	6.8K ohms
R-617	33101-104	100K ohms
R-618	33101-470	47 ohms
R-619	33101-392	3.9K ohms
R-620	33101-822	8.2K ohms
R-621	33101-473	47K ohms
R-622	33101-683	68K ohms
R-623	33101-473	47K ohms
R-624	33101-473	47K ohms

PARTS LIST (Cont.)

Ref. No.	NuTone Part No.	DESCRIPTION
RESISTORS		
R-625	33101-103	10K ohms
R-626	33101-682	6.8K ohms
R-627	33101-331	330 ohms
R-628	33101-224	220K ohms
R-629	33101-224	220K ohms
R-630	33101-392	3.9K ohms
R-631	33101-392	3.9K ohms
R-632	34046 Potentiometer	350K ohms
RELAYS		
RY-1	39038	Talk/Listen
RY-2	39119	Door
RY-3	39119	Standby
RY-4	39120	Stepping
RY-4 Ass'y	41136	Complete relay ass'y including plug, indicator and bracket
INDICATOR		
I-1	39123	Indicator for RY-4
SWITCHES		
SW-1 to SW-12	34596	4 pos. rotary Remote Speaker Selector
SPEAKER		
SP-1	36017	5" 45 ohm
PUSHBUTTONS		
PB-1	3721	FM Change
PB-2	3721	AM/FM
PRINTED CIRCUIT BOARD ASSEMBLIES		
PCB-1	41146	Intercom Control
PCB-2	41133	Remote Station Selector
PCB-3	41133	Remote Station Selector
PCB-4	41134	Door — Inside Talk/Listen P/C board and switch ass'y.
KNOBS		
K-1	39058	Master Station Volume
K-2	39118	Remote Station Selector

3721 } 42589-000