


EFFECTIVE DATE
August 1, 1968

NuTone

MODEL
2550 "B"

PARTS LIST



REF.	PART NO.	PART DESCRIPTION
1	40688	Panel Assembly
2	32403	Panel Only
3	36017	Speaker
4	40616	P. C. Board & Knob Assembly
5	31850	Volume Knob
6	34576	Push Switch - 6 Pole
7	34575	Push Switch - 2 Pole
8	37516	P. C. Board Only
9	34021	Potentiometer
10	31878	Pushbutton (2 required)
--	40690	Envelope Assembly (Not Shown)

PRICES SUBJECT TO CHANGE WITHOUT NOTICE

Order Parts From: PARTS DEPT. C/O

NuTone