

EFFECTIVE


May 1, 1967

NUTONE

MODEL

412

PARTS - LIST



REF	PART-NO.		PART DESCRIPTION
1	32268	*	Mounting Plate
2	36015	*	Speaker, 3-1/2"
3	32267	*	Cover Box w/Ref. No. 4.
4	32271	*	Grille
5	40435		Switch and Insert Assembly Ref. No's 6 and 7.
6	32269		Switch Insert
7	34546		Switch (Including Nut and L' Washer)
8	40437		Envelope Assembly (Blank Insert)
-	40436		Envelope Assembly (Mounting Screws)

PRICES SUBJECT TO
CHANGE WITHOUT NOTICE

Order Parts From: NUTONE, INC.
P. O. BOX 27
Cincinnati, Ohio 45227

Printed in U. S. A.

*Part used on other model/s