

PARTS LIST FOR MODEL 477 CONTROL

REF. NO.	NUTONE PART NUMBER	DESCRIPTION
----------	--------------------	-------------

TRANSISTORS

TR-1	36577	
TR-2	36597	(Motorola 2N4870)
TR-3	36597	(Motorola 2N4870)
TR-4	36580	
TR-5	36580	
TR-6	36580	
TR-7	36591	(Motorola MPS 6530)
TR-8	*36592	(Motorola MPS 6533)
	36603	(Motorola MPS U55)
TR-9	36577	
TR-10	36586	(Motorola MPS 1315)
TR-11	36590	(Motorola MPS A13)
TR-12	36590	(Motorola MPS A13)
TR-13	36586	(Motorola MPS 1315)
TR-14	36587	(Motorola MPS 6517)
TR-15	36587	(Motorola MPS 6517)
TR-16	36580	
TR-17	*36588	(Motorola MPS U51)
	36603	(Motorola MPS U55)

* Used in early production

DIODES

D-1	36595	(Motorola 1N5245)	15V Zener
D-2	36549	(Motorola 1N4002)	
D-3	36549	(Motorola 1N4002)	
D-4	36549	(Motorola 1N4002)	
D-5	36549	(Motorola 1N4002)	
D-6	36549	(Motorola 1N4002)	
D-7	36549	(Motorola 1N4002)	
D-8	36549	(Motorola 1N4002)	
D-9	36549	(Motorola 1N4002)	
D-10	36553		
D-11	36594	(Motorola 1N5234)	6.2V Zener
D-12	36553		
D-13*	36553		
D-14	36549	(Motorola 1N4002)	
D-15*	36549	(Motorola 1N4002)	
D-16	36549	(Motorola 1N4002)	
D-17	36549	(Motorola 1N4002)	
D-18	36549	(Motorola 1N4002)	
D-19	36549	(Motorola 1N4002)	
D-20	36549	(Motorola 1N4002)	
D-21	36549	(Motorola 1N4002)	
D-22	36549	(Motorola 1N4002)	
D-23	36549	(Motorola 1N4002)	
D-24	36549	(Motorola 1N4002)	
D-25	36549	(Motorola 1N4002)	
D-26	36549	(Motorola 1N4002)	
D-27	36549	(Motorola 1N4002)	

* Early production only

PARTS LIST FOR MODEL 477 CONTROL (cont'd)

REF. NO.	NUTONE PART NUMBER	DESCRIPTION
----------	--------------------	-------------

CAPACITORS

C-1	35100-148	.015 mfd 50V
C-2	35068-113	50 mfd 25V
C-3	35068-106	2 mfd 50V
C-4	35068-106	2 mfd 50V
C-5	35024-101	.47 mfd 75V
C-6	35024-101	.47 mfd 75V
C-7	35076-104	.082 mfd 12V
C-8	35100-141	.05 mfd 50V
C-9	35100-155	.0027 mfd 50V
C-10		
C-11	35085-102	1100 mfd 25V

RESISTORS

R-1		47K ohms
R-2		4.7K ohms
R-3		470K ohms
R-4		560K ohms
R-5		4.7K ohms
R-6		47K ohms
R-7		470K ohms
R-8		680K ohms
R-9		100K ohms
R-10		27 ohms
R-11		47K ohms
R-12		27K ohms
R-13		1.2K ohms
R-14		68 ohms
R-15		68K ohms
R-16		1.2K ohms
R-17		100K ohms
R-18		47K ohms
R-19		68 ohms
R-20		4.7K ohms
R-21		6.8K ohms
R-22		330K ohms
R-23		220K ohms
R-24		6.8K ohms
R-25		5.6K ohms
R-26		150 ohms
R-27		47K ohms
R-28		2.2K ohms
R-29		4.7K ohms
R-30		1K ohms
R-31		47K ohms
R-32		4.7K ohms
R-33		560K ohms
R-34		47K ohms
R-35		4.7K ohms
R-36		4.7K ohms
R-37		27K ohms
R-38		27K ohms

PARTS LIST FOR MODEL 477 CONTROL (cont'd)

REF. NO.	NUTONE PART NUMBER	DESCRIPTION
----------	--------------------	-------------

RESISTORS (cont.)

R-39	34042	Potentiometer	100K ohms
R-40	34043	Potentiometer	500K ohms
R-41	34043	Potentiometer	500K ohms
R-42	34041	Potentiometer	50K ohms
R-43			4.7 Meg ohms
R-44			180 ohms
R-45			180 ohms
R-46			27 ohms
R-47			4.7K ohms
R-48			6.8K ohms
R-49			10K ohms
R-50			47 ohms
R-51			4.7K ohms
R-52			6.8K ohms
R-53			6.8K ohms
R-54			4.7K ohms

RELAYS

CR-1	36039		LPB.
CR-2	39038		4PDT
CR-3	39038		4PDT
CR-4	39039		2PDT

TRANSFORMER

T-1	30536		Audio Input
-----	-------	--	-------------