

REF.	ORIGINAL PART NO.	*PART DESCRIPTION	MODEL USED ON	CURRENT REPLACEMENT PART NO.	
1	96027	DOOR ASSEMBLY COMPLETE	D-141	96027-000	
	96028		D-142	96028-000	
			D-142-18		
	96029		D-143	96029-000	
	96037		D-144	96037-000	
			D-144-18		
	96169		D-145	96169-000	
	96973		D-146	96973-000	
D-146-18					
2	90743	SHELF—4" x 13¼"	ONE	ALL MODELS	90743-000
	90042		SET OF TWO	D-142-18 D-144-10 D-146-18	90042-000
	90742		SET OF THREE	D-141, D-142 D-143, D-144 D-145, D-146	90742-000
3	90011	MAGNETIC CATCH		90011-000	
4	2093A	BUMPER SET (2)	ALL MODELS	2093A-000	
5	90075	HINGE PIN		90075-000	
6	92268	HARDWARE ASSEMBLY	D-141, D-142 D-143, D-144 D-145, D-146	92268-000	
	92265		D-142-18 D-144-18	92265-000	
	90141		D-146-18	90141-000	
7	90039	SHELF SUPPORT		90039-000	
8	92264	TOOTHBRUSH HOLDER	ALL MODELS	92264-000	
9	52842	SCREW SET—(6) NO. 8 x 1¼ PH. PAN HD. "A"		69781-000	

↑
NOTE: Always order by current part number.