


NUTONE
DK-308
 Non-Electric
 Parts List



DK-308 CAROLEER		Description Size Chime Operation	Oyster White or Dark Antique Copper	List Price
ILLUSTR. NO.	PART NO.	PART DESCRIPTION		NOTES
1	2837	Base Plate Complete (Mechanism) (Includes Reed Assembly, Activating Arm Assembly)		Adjustable fits metal or wood doors $\frac{7}{8}$ " to 2 $\frac{1}{4}$ " For doors thicker than 2 $\frac{1}{2}$ " or for installation in walls up to 9". Ask for shaft EX 310.
2	2836	Base Plate Only (Reed Stud, Upper and Lower Bearing)		
3	1515	Right Hand Reed Assembly (Includes Grommet)		
4	1514	Left Hand Reed Assembly (Includes Grommet)		
5	2492	Activating Arm Assembly (Striker Arm) (Includes Arm Spring, Bearing Assembly)		
6	6675	Front Base Plate (Includes Trunion Supports, Bushing, Trunion Assembly, Cam Shaft and Handle)		
7	6676	Cam and Shaft Assembly		
8	6068	Trunion Assembly (Includes Trunion Assembly, Spring and Trunion Shaft)		
9	6677	Escutcheon Plate (Includes Bezel, Window, Card, Backing)		
10	6045	Bezel		
11	2452	Cover		

PRICES SUBJECT TO CHANGE WITHOUT NOTICE

Order Parts From: PARTS DEPT. C/O

NuTone

*Part used on other model/s

Madison and Red Bank Rds., Cincinnati, O. 45227

Printed in U.S.A.