


EFFECTIVE DATE
June 1, 1968

NuTone

MODEL
DP-5SA6 DP-5GA6
DP-5SA12 DP-5GA12

PARTS LIST



REF.	PART NO.	PART DESCRIPTION
<u>COMMON PARTS</u>		
1	24079	Mechanism Housing
2	24081	Pushbutton
3	24082	Spring Contact
4	16756	Tinnerman Clip
-	24083	Terminal Plate (Not Shown)
-	24097	Support Channel (Not Shown)
<u>MODEL DP-5SA6</u>		
5	24108	Pushbutton Panel Complete
6	24114-14	Panel
7	24088	Contact Rod Assembly
-	24098	Envelope Assembly (Not Shown)
<u>MODEL DP-5SA12</u>		
8	24109	Pushbutton Panel Complete
9	24115-14	Panel
10	24089	Contact Rod Assembly
-	24098	Envelope Assembly (Not Shown)

(PLEASE SEE OTHER SIDE)

PRICES SUBJECT TO CHANGE WITHOUT NOTICE

Order Parts From: PARTS DEPT. C/O

NuTone

REF.	PART NO.	PART DESCRIPTION
<u>MODEL DP-5GA6</u>		
11	24110	Pushbutton Panel Complete
12	24114-19	Panel
13	24088	Contact Rod Assembly
-	24101	Envelope Assembly (Not Shown)
<u>MODEL DP-5GA12</u>		
14	24111	Pushbutton Panel Complete
15	24115-19	Panel
16	24089	Contact Rod Assembly
-	24101	Envelope Assembly (Not Shown)

PRICES SUBJECT TO CHANGE WITHOUT NOTICE

Order Parts From: PARTS DEPT. C/O

NuTone

*Part used on other model/s

Printed in the U.S.A.