


PARTS LIST

MODEL	IC-21 ELECTRONICS
EFFECTIVE DATE	NEW JANUARY, 1974



REF.	ORIGINAL PART NO.	PART DESCRIPTION	MODEL USED ON	CURRENT REPLACEMENT PART NO.
1	13650-900	REMOTE CONTROL COMP.	IC-21	13650-900
2	38571-000	BEZEL	IC-21	38571-000
3	41579-000	ENVELOPE ASSY. (Mtg. Screws)	IC-21	41579-000
4	34063-000	POTENTIOMETER	IC-21	34063-000
5	25056-003	WASHER	IC-21	25056-003
6	31403-000	WASHER	IC-21	31403-000
7	38536-051	CONTACT WIRE	IC-21	38536-051
8	31405-051	CONTACT (1) 2-Required	IC-21	31405-051
9	31455-003	SCREW	IC-21	31455-003
10	38558-000	CONTROL INSERT	IC-21	38558-000
11	39342-000	PUSHBUTTON	IC-21	39342-000
12	39344-000	KNOB - VOL.	IC-21	39344-000
13	69802-000	CONTROL INSERT ASSY.	IC-21	69802-000

NuTone Division

Order Parts From:
Parts Department c/o NuTone
P.O. Box 27 • Cincinnati, Ohio 45227

NOTE: Always order by
current part number