


NUTONE
Model
L-32
DOOR CHIME
Parts List



L-32 Model		Description PROVINCIAL (WALNUT)	
ILLUSTR. NO.	PART NO.	PART DESCRIPTION	NOTES
1	5802	Base Plate Assembly Complete (Includes Tubes Reed Assemblies, Power Units Complete)	Use 101-OB Transformer
2	5830-5	R.H. Resonator Assembly	Resonator assembly includes resonator, tuning cap, speed nut, and reed stud.
3	5831-5	L.H. Resonator Assembly	
4	4781	R.H. Inside Reed Assembly (Includes Grommets)	Clean sticky plungers with lighter fluid.
5	4780	R.H. Outside Reed Assembly (Includes Grommets)	
6	3388	L.H. Inside Reed Assembly (Includes Grommets)	DO NOT OIL.
7	3389	L.H. Outside Reed Assembly (Includes Grommets)	
8	6526	Cover Assembly (Includes Cover and Brkt. — Grille Cloth and Backing, Eyelets, Rivets and Speed Nuts)	

PRICES SUBJECT TO CHANGE WITHOUT NOTICE

Order Parts From: PARTS DEPT. C/O

NuTone

*Part used on other model/s

Madison and Red Bank Rds., Cincinnati, O. 45227

Printed in U.S.A.