



PARTS LIST

EFFECTIVE DATE	MODEL NUMBER	PRODUCT GROUP
OCTOBER 1994	L-38, L-38N, LA-38, LB-38, LC-38, LD-38 REVISED	CHIME



NuTone

NuTone
 Attn: Parts Department
 Madison & Red Bank Rds.
 Cincinnati, OH 45227-1599
 Phone: (513) 527-5426
 Fax: (513) 527-5173

REF.	ORIGINAL PART NO.	*PART DESCRIPTION	MODEL USED ON	CURRENT REPLACEMENT PART NO.	
1	07055	COVER – See Note	WALNUT	Void - not avail.	
	07056		LIME OAK		
	09250		WALNUT		
	09251		BLOND ELM		
	00698		WALNUT		
	00699		BLOND ELM		
	65365		DARK OAK		
	65366		WHITE OAK		
	53114		MAHONGANY		
2	07030	MECHANISM ASSEMBLY – With Gold Tubes	L-38	Void - not avail.	
	08710		L-38N, LA-38		
	64165		LB-38, LC-38		
	53136		LD-38		
3	69578	RESONATOR TUBE ASSY	GOLD	L-38, L-38N, LA-38 LB-38, LC-38, LD-38	69578-000
	69717		ALUMINUM	LC-38	Void - not avail.
4	07158	REED SET – With Grommets	All Models	07158-000	
5	69579	GROMMET SET – 6	All Models	69691-000	
6	69684	P.C. BOARD AND MOTOR ASSEMBLY	All Models	Void - not avail.	
7	1154A	MOTOR ASSEMBLY	All Models	Void - not avail.	
8	--	SLIDE SWITCH	L-38	Not Used	
	08724		L-38N, LA-38, LB-38, LC-38	69543-000	
	69543		LD-38		
9	--	STARTING CONTACT	L-38, L-38N, LA-38	Not Used	
	64170		LB-38, LC-38, LD-38	65697-051	
10	04425	ROTOR ASSEMBLY	L-38	Void - not avail.	
	08721		L-38N, LA-38	64173-000	
	64173		LB-38, LC-38, LD-38		
11	04774	P.C. BOARD	L-38	Void - not avail.	
	69700		L-38N, LA-38		
	64168		LB-38, LC-38, LD-38		
12	64166	BASE PLATE ASSEMBLY	All Models	Void - not avail.	
13	69677	PLUNGER SET – 3 Plunger, Spring, Cap	All Models	69581-000	
14	07149	POWER UNIT ASSEMBLY – 1 With Plunger, Springer, Cap	L-38	08135-000	
	08136		L-38N, LA-38, LB-38, LC-38, LD-38		

NOTE: LC-38 AND LD-38 CHIME COVERS
WILL FIT OLDER MODELS

NOTE: Always order by
current part number