

PARTS LIST FOR MH-7, MH-13, 2035B

COILS

L 2	60230	Antenna
L 5	60231	Oscillator
L 9	60235	8.2 MH Choke
L10	30074	RF Choke

TRANSFORMERS

T 3	60239	1st IF
T 5	60291	2nd IF
T 7	60292	3rd IF
T 9	60243	Driver
T10	60242	Power
T11	60244	Output
T12	30529	Intercom Input (not used on MH-7)

COMBINATION COMPONENTS

M 2	60250-331	Capristor
M 3	60250-315	Capristor
M 4	60250-332	Capristor
M 8	60250-303	Capristor
M11	34563	Talk/Listen Switch (not used on M-7)
M12	34567	Door Switch (not used on M-7)
M13	60281	Thermistor
M14	60281	Thermistor
M15	60293	AM/Aux Switch

DIODE

D1	60280
D4	60280
D6	60245
D7	60245

TRANSISTORS

TR 1	60298	Converter
TR 2	60299	IF
TR 3	60274	IF
TR 7	60277	Audio
TR 8	60277	Driver
TR 9	60278	Output
TR10	60278	Output

RESISTORS

R 1	60247	Volume Control/Switch
R 2		10K
R 3		33K
R 4		68K
R 5		1.5K
R 6		33K
R 8		4.7K
R 9		2.2K
R26		33K
R33		470K
R34		6.8K
R35		470
R36		1.5K
R37		220K
R38		68K
R39		68K
R40		47
R41		150
R42		2.2K
R43		100
R44		1
R45		2.2K
R46		100
R47		1
R49		100
R50	60248	200K Level-set
R52		4.7K
R53		1.5 (not used on MH-7)
R54	34033	50 Intercom Volume (not used on MH-7)
R55		1.5 (MH-7 only)
R58		2.2K
R59		22 (not used on MH-7)
R60		15K
R61		1 Meg
R62		180K

CAPACITORS (50V unless otherwise noted)

C1-C2	60249	Tuning Gang
C 3	60295	Trimmer Assy.
C 4	60295	Trimmer Assy.
C 5		.01 Mfd Mylar
C 6		33 Mfd 6V Electrolytic
C 7		.04 Mfd 25V Discap
C 8		7 Pfd Discap
C 9		4 Pfd Discap
C10		.01 Mfd Mylar
C11		300 Pfd Discap
C40		.01 Mfd Mylar
C42		33 Mfd 12V Electrolytic
C44		220 Mfd 16V Electrolytic
C46		1 Mfd 50V Electrolytic

PARTS LIST FOR MH-7, MH-13, 2035B

CONDENSER (continued)

C47	10 Mfd 10V Electrolytic
C48	10 Mfd 10V Electrolytic
C49	10 Mfd 10V Electrolytic
C50	1000 Mfd 16V Electrolytic
C51	.01 Mfd Mylar
C52	.01 Mfd Mylar
C53	1000 Mfd 16V Electrolytic
C54	.01 Mfd Mylar
C55	300 Pfd Barium
C56	1000 Mfd 16V Electrolytic
C58	.005 Mfd Mylar
C59	.005 Mfd Mylar
C60	.005 Mfd Mylar
C61	.05 Mfd Mylar
C62	.002 Mfd Styroc
C63	10 Pfd Ceramic
C64	160 Pfd Barium
C65	15 Pfd

MISCELLANEOUS

60220	Dial Pointer
60221	Dial
60224	Dial Shaft
60225	Dial Pulley Wheel
60226	Spring—Dial Cord
60251	Screw—Dial
60252	Screw—Dial Pulley
60255	Cord—Dial
60223	Radiator—output (Heat Sink)
32569	Interlock Cord and Plug (not used on 2035B)
40836	Front Panel Assembly (MH-7)
40838	Front Panel Assembly (MH-13)
40834	Front Panel Assembly (2035B)
36049	Speaker 3.2 Ohm (MH-7)
36025	Speaker 3.2 Ohm (MH-13, 2035B)
40831	Mounting Hardware (MH-7, MH-13)
40438	Mounting Hardware (2035B)
31964	Knob Radio
31965	Knob Intercom (not used on MH-7)
40840	Intercom Assembly (not used on MH-7)