



Model RC-1 Record Changer

MODEL RC-91 RECORD CHANGER PARTS LIST

Ref. No.	NuTone Part No.	BSR Part No.	Description
1	60991	A100762	Circlip
2	60992	A100785	Circlip
3	60995	A104077	Circlip
4	60998	A102126	Solder Tag
5	61019	A102109	Circlip
6	61025	A108334	Circlip
7	61030	A105660	Control Washer
8	61261	A101646	Washer
9	61262	A102181	Rubber Mount
10	61266	A106749	4BA Tag Lockwasher
11	5079-A	A105678	Circlip
12	5121-A	A101620	Jockey Spindle Washer
13	5122-A	A101623	Jockey Pulley
14	5123-A	A102595	washer
15	5125-A	A104189	Transit Screw
16	5130-A	A102616	Phono Socket
17	5132-A	A106510	Screw Type "B" #6 x 1/4" Slt. Pan Hd.
18	5136-A	A108891	Selector Pivot Spring
19	5137-A	A108894	Selector Pivot
20	5140-A	C108483	Main Sub Plate Riveting Assy.
21	5142-A	A108893	Washer
22	5144-A	A108654	Spring Clip
23	5151-A	A108461	Roller
24	5153-A	A108078	Selector Driver Spring
25	5154-A	A108077	Spring
26	5155-A	A103290	Washer
27	5156-A	A106980	Operating Plate Spring
28	5157-A	A106966	Washer
29	5159-A	A107419	9/64" Dia. Ball Bearing
30	5160-A	A106962	Actuating Slide
31	5161-A	A106511	Screw Type 25, 4 - 24 x 1/2 Pan Hd.
32	5162-A	A102237	Washer
33	5163-A	A104384	Leaf Spring
34	5164-A	A105609	Spring Support
35	5165-A	B108073	Toggle Switch
36	5168-A	A106968	Feed Lever
37	5169-A	A105827	Link Return Spring
38	5170-A	B105597	Feed Lever Link
39	5171-A	A102251	Retainer
40	5172-A	A102623	Cut-off Lever Spring
41	5173-A	A101526	Circlip
42	5174-A	B105592	Cut-off Lever
43	5176-A	A102128	Circlip
44	5177-A	A106627	Detent Spring
45	5178-A	B108036	Selector Lever
46	5179-A	A108033	Detent Plate
47	5180-A	A108083	Cut-off Slide Spring
48	5181-A	A108075	Detent Plate Spring
49	5183-A	A104882	Retaining Clip
50	5184-A	A102058	Damping Washer
51	5185-A	A101506	Thrust Washer
52	5186-A	A101649	Ball Race
53	5187-A	A102133	Cam Gear Riveting Assy.
54	5188-A	A108238	Reject Lever Assy.
55	5189-A	A108064	Slide Pin
56	5191-A	A102110	Circlip
57	5192-A	A106819	Actuating Pawl Assy.
58	5193-A	A105263	Screw Type 25, #6 - 20 x 3/8 Pan Hd.
59	5195-A	A104865	Insulating Strip
60	5198-A	A105831	Raising Spindle Spring
61	5202-A	A105619	Adjusting Screw
62	5203-A	A105965	Jockey Arm Riveting Assy.
63	5204-A	A105824	Jockey Pulley Spring
64	5212-A	A105826	Switch Lever Spring
65	5213-A	A105712	Adjusting Screw
66	5293-A	A107043	Spindle
67	5296-A	B106139	Turntable Trim
68	5303-A	A106090	Mounting Spring
69	5305-A	A102166	Retaining Clip
70	5312-A	A108168	Operating Plate Assy.
71	5316-A	A107154	5/32" Ball Bearing

Ref. No.	NuTone Part No.	BSR Part No.	Description
72	5319-A	A105901	Activating Slide Spring
73	5322-A	B108285	Switch Ass'y.
74	5323-A	B106021	Speed Change Arm
75	5324-A	A106034	Speed Change Bracket
76	5325-A	A108589	Raising Spindle
77	5331-A	A106134	Reject Link
78	5332-A	A106193	Reject Plate Ass'y.
79	5338-A	A106129	Switch Lever
80	5339-A	A106405	Switch Link
81	5352-A	A106089	Spring Cup
82	5728-A	B112159	Speed Change Link
83	5729-A		P. U. Lead & Sleeve Ass'y.
84	5730-A	A105268	Screw Type B.T. #4 - 24 x 9.5 Rec. Pan Hd.
85	5731-A	B113132	Main Plate Sub Ass'y.
86	5732-A	A113121	P. U. Raising Spindle Ass'y.
87	5733-A	B113120	Quadrant Ass'y.
88	5734-A	A108514	Screw Type B, #2 x 4.5 Rec. Pan Hd.
89	5735-A	A111516	Molex Plug
90	5736-A	A113128	Control Plate Riv. Ass'y. (Speed Change)
91	5737-A	B112234	Raising Cam
92	5738-A	A113129	Control Plate Riv. Ass'y. (Stop/Start/Auto)
93	5739-A	A113096	Reject Slide
94	5740-A	A112152	Selector Connecting Link
95	5741-A	A112167	Cut-off Slide
96	5742-A	A113130	Control Plate Riv. Ass'y. (Size Selector)
97	5743-A	A112253	Muting Switch Ass'y.
98	5744-A	B113131	Control Arm Ass'y.
99	5745-A	D113106	Turntable Moulding
100	5746-A	A113462	Control Knob Ass'y.
101	5747-A	A113095	Pick-Up Clip
102	5748-A	A113123	Escutcheon Trim
103	5749-A	C113092	Escutcheon
104	5750-A	A113441	Cue Assembly
105	5751-A	D113091	Control Housing
106	5752-A	A113094	Nut
107	5753-A	A113124	Circlip
108	5754-A	B113105	Pick-Up Hinge
109	5755-A	A113355	Pick-Up Body Sub Ass'y.
110	5756-A	B112486	Pick-Up Head
111	5757-A	A106206	Tag Mounting Strip
112	5758-A		Two Pole Motor Ass'y. & Sleeving
113	5759-A	A102718	Cable Clamp
114	5760-A	A106970	Capacitor
115	5761-A	A108184	Switch Cover (Used w/ Pop Filter)
116	5762-A	B111153	T. T. Centre Disc.
117	5763-A	A106573	Screw Type 6 B.A. x 4.5 Rec. C'Sunk Hd.
118	5764-A	A108797	Screw Type B #4 x 4.5 Rec. Pan Hd.
119	5765-A	A113104	Set Down Adjuster
120	5766-A	A106775	Adapter Plate
121	5767-A	A105265	Screw Type B.T. #4 - 24 x 4.5 Rec. Pan Hd.
122	5768-A	A09-370	Pick-Up Tube
123	5769-A	A09-144	P. U. Pivot Screw
124	5770-A	A09-142	Balance Indicator
125	5771-A	A017012	Screw (Set Down)
126	5772-A	A09-328	Cueing Knob
127	5773-A	A09-388	Retaining Spring
128	5774-A	A09-340	Spring (Set Down)
129	5775-A	A09-352	Thrust Washer
130	5776-A	A09-456	Locknut (P. U. Spindle)
131	5777-A	A09-145	P. U. Balance Screw
132	5778-A		Spring (P. U. Balance)
133	5801-A	TC11MO	Cartridge
134	5802-A	T3MD	Needle Stylus
135	5086-A	A106745	Pick-Up Lead
136	5893-A	A113137	178mm - 3mm P.V.C. Sleeving





Tone Arm Ass'y. Complete
1564-A