


Parts RM-65000

SERVICE PARTS - LISTE PIECES DE RECHANGE - LISTA DE PIEZAS DE RECAMBIO

MODEL K274



SERVICE PARTS

MODEL K274

KEY NO.	PART NO.	DESCRIPTION
6	B02000191	Filter Spring
9	B08087298	Grease Filter
14	B02300233	Motor Capacitor
16	B08091202	Electrical Box Support
19	B03295005	Terminal Cover
26	B02300668	Halogen Lamp Bulb
38	B03292357	Control Board Box
39	B03294033	Control Board Cover
42	B03295002	Ductfree Filter Bracket
48	B02310185	Motor
49	B03295071	Blower Wheel
53	B03202007	Hubber Washer
57	B02000756	Damper Flap
60	B02300249	Feeder Cable
68	B02000295	Right Blower Housing
69	B02000296	Left Blower Housing
73	B002010000	Glass
99	BE3342052	Filter Channel
108	B032921370	Terminal Block Protection
113	B03202433	Nameplate
114	B03290499	Runner Wires
118	BE3342055	Decorative Flue Bottom
119	BE3342056	Decorative Flue Top
120	BE3342057	Flue Mounting Bracket
123	B03292283	Discharge collar
135	B03292362	Trimming
144	B03292287	Wire Clamp
147	BR2300132	Terminal Block
151	B032920200	Electrical Box Wires Stop
154	B03202286	Fairlead
165	B03295008	Control Box
166	B08086661	Control Board
170	BE3342104	Reinforcement
196	B02009193	Reflector
199	B02300688	Lamp Socket
200	B02009103	Lamp Shroud
208	B02300783	Transformer
223	B03202296	Switch Button
228	B08086253	Controls Board
230	B03292477	Switch Board Box Cover
234	B03292476	Control Board Box
250	B02009102	Ring Nut
373	BE3341633	Transformer Bracket
387	BE3342079	Glass Right Stop
388	BE3342043	Glass Left Stop
477	B03295006	Terminal Cover
*	B06001989	Blower Assembly (Includes Key Nos. 42, 48, 49, 53, 68, 69)
*	B06107341	Switch Box Assembly (Includes Key Nos. 234, 228, 223, 230, 135)
-	B02300782	Fuse
-	B02300674	Fuse Holder

* Not shown assembled.