EFFECTIVE DATE
June 1, 1971

NuTone
PARTS LIST

MODEL
2513 B
Electronics



REF.	PART NO.	*Part used on other model/s	PART DESCRIPTION
1	41099		"B" Unit Complete
2	36017		Speaker - 45 Ohm
3	38226		Bracket - PC Board
4	39088	*	Spacer - 2 required
5	41212	*	PC Board Assy.
6	34587	*	Switch - 4 required
7	31568	*	PC Board only
8	31878	*	Pushbutton - 4 required
9	34044	*	Potentiometer
10	38188		Panel
11	39089	*	Knob
12	3721	*	Pushbutton Complete
--	31871		Mounting Screws - 2 required (not shown)

Order Parts From: PARTS DEPT. C/O

NuTone SCOVILL
DIVISION